

SUPPLEMENTARY MATERIAL

An Efficient Chemical Synthesis of Lassomycin Enabled by an On-Resin Lactamisation/Off-Resin Methanolysis Strategy and Preparation of Chemical Variants

Paul W. R. Harris,^{A,B,E} Gregory M. Cook,^{B,D} Ivanhoe K. H. Leung,^A and Margaret A. Brimble^{A,B,C}

^ASchool of Biological Sciences, The University of Auckland, 3A Symonds Street, Auckland 1010, New Zealand.

^BMaurice Wilkins Centre for Molecular Biodiscovery, The University of Auckland, 3A Symonds Street, Auckland 1010, New Zealand.

^CSchool of Chemical Sciences, The University of Auckland, 23 Symonds Street, Auckland 1010, New Zealand.

^DDepartment of Microbiology and Immunology, School of Medical Sciences, University of Otago, 720 Cumberland Street, Dunedin 9054, New Zealand.

^ECorresponding author. Email: paul.harris@auckland.ac.nz





Figure S1. HPLC monitoring (214 nm) of the thioetherification reaction for the preparation of Lassomycin [¹Gly-COCH₂-⁸Cys] **12**, left T = 0, right T = 30 mins. At T = 0 the reaction is *ca.* 40% complete. The earlier eluting material from 0-9 mins are buffer components.




Figure S2. LC-MS of purified Lassomycin [$^1\text{Gly-COCH}_2\text{-}^8\text{Cys}$] **12**. Deconvolution yields a mass of 1911.0 ± 0.4 Da. The calculated mass is 1911.28.





Figure S3. LC-MS of Lassomycin [¹Gly-⁸Glu] **13**. Deconvolution yields a mass of 1865.8 ± 0.2 Da. The calculated mass is 1866.2. The later eluting peak at *ca.* 21 mins is a non-peptide column contaminant.





Figure S4. LC-MS of Lassomycin [¹Gly-⁹Glu] **14**. Deconvolution yields a mass of 1879.1 ± 0.2 Da. The calculated mass is 1879.2. The later eluting peak at *ca.* 21 mns is a non-peptide column contaminant. (LS-MS is wrong!)







Figure S5. TOF-MS and MS/MS comparison of synthetic Lassomycin **1** and natural Lassomyin.




Figure S6. NMR comparison of synthetic Lassomycin **1** (red) and natural Lassomycin (blue); (a) ^1H NMR of the aliphatic region and (b) ^1H - ^{13}C HSQC overlay of the same region. The asterisk (*) on (b) denotes impurities from the commercial obtained natural Lassomycin; (c) and (d) ^1H - ^1H NMR TOSCY spectra of the NH fingerprint region of Lassomycin **1** (red) and natural Lassomycin (blue).





Figure S7. ^1H - ^{13}C HSQC of synthetic Lassomycin (red) and natural Lassomycin (blue) indicating both peptides are effectively the same.